



**JB JETBLACK™**

# ***FREEDOM ROCKER FEET***

**USER MANUAL**

OCTOBER 2025

# ***CONTENTS***

Welcome to the JetBlack Freedom Rocker Feet	3
What's in the box	4
How it works	4
Installation & Inflation	5
Inflation guide	6
Removing your Freedom Rocker Feet	6
Support & contact information	6

# ***WELCOME TO THE JETBLACK FREEDOM ROCKER FEET***


**At JetBlack, we LOVE to RIDE, that is why we have thought of every detail to make your indoor riding experience great!**

Before you get started, please read and follow all set up instructions


***SCAN OR CLICK TO WATCH INSTRUCTIONAL VIDEO***



## WHAT'S IN THE BOX



OR



## HOW IT WORKS

When inflated, the inner circumference on the Freedom Rocker Feet get smaller. When this happens, the inflatables grip the trainer's rubber feet.

**UNLIKE FULL ROCKER PLATES, THE JETBLACK FREEDOM ROCKER FEET BRINGS ABOUT SUBTLE MOVEMENTS TO TAKE AWAY THE TENSION ON THE SADDLE AND HANDLE BARS THAT CAN OCCUR WHEN RIDING INDOORS.**

When using the Freedom Rocker Feet you will find yourself sitting on the sweet spot on your saddle for much longer.

The forgiving movement of the Freedom Rocker Feet not only helps with your sit bones, but it also assists your knees, hips, shoulders and wrists to mobilise providing a freedom of movement similar to riding outdoors.

## FEATURES

- + Ergonomic
- + Adjustable
- + Easy Assembly
- + Portable
- + Compatible
- + Stable
- + Innovative
- + Affordable

# INSTALLATION & INFLATION

## INSTALLATION

### STEP 1


Fit the Freedom Rocker Feet to your trainer's legs while deflated.

### STEP 2

Ensure you leave the trainer's original rubber feet on the legs.


### STEP 3

Ensure the Freedom Rocker Feet valves are all pointing to the outside for easy access




### STEP 4

Ensure your Freedom Rocker Feet are evenly spread on the floor




### STEP 5

Looking down at your Freedom Rocker Feet, ensure they are flush with your leg ends.



### STEP 6

And are parallel to your trainer's direction.




## INFLATION

### STEP 7

Insert the needle firmly to activate the valve.

**NOTE:** This may cause a slight 'pop' noise as the seal on the valve is opened.



## **INFLATION SETTINGS**

Freedom Rocker Feet are adjustable to suit rider weight and ride feel. Experiment with pressures from 5PSI upwards.

DO NOT exceed 15PSI.

**NOTE: Rider weight limit is 120kg**



### **IMPORTANT NOTES ON INFLATION**

- **Do not inflate over 15PSI**
- **Over-inflation will cause the trainer to become unstable during big efforts**
- **Check your Freedom Rocker Feet pressure regularly before riding.**

## **REMOVING YOUR FREEDOM ROCKER FEET**

Remove the needle adapter from the end of your pump hose and insert gently into the valve. This will release the air from your Freedom Rocker Feet enabling you to remove them with ease.

### **ADDITIONAL SUPPORT**

#### **CONTACT JETBLACK**

For more information or support on Freedom Rocker Feet

[jetblackcycling.com/support](https://jetblackcycling.com/support)

JetBlack Products  
31 Walker Street  
South Windsor NSW  
Australia.

Email: [info@jetblackcycling.com](mailto:info@jetblackcycling.com)